



Chromebook Getting Started – Visual Guide

Once you have unboxed and plugged in your Chromebook – you are ready to get started.




The Chromebook will normally power on when you lift the lid but use the power key to turn it on if it does not start automatically.




Power Key

Join the Chromebook to your home Wi-Fi or use the Mi-Fi dongle if that has been supplied.




Open the Wi-Fi panel and connect to your wireless system

Now you can login with the details given to you by your school.



Once you are logged in, your home page on the internet will display.



You are now ready to start browsing and access the Office 365 platform for schoolwork.

Video Support

You can access our Chromebook video guides here:

<https://www.youtube.com/playlist?list=PLTGzH9gO0megKz6OUBeAmnc2GwLqRp3i3>

Shot form link: <https://bit.ly/2AGuoMr>